ODYSSEY
#1 PUTTER ON TOUR.

# PUTTER FITTING CHART

## TOE HANG

| | TOE UP (90° UP) | FACE BALANCED (0°) | MINIMAL (10°–30°) | MID (31°–50°) |
|---|---|---|---|---|
| FRONT CG | **Tri-Hot Square 2 Square** Seven**<br>**Tri-Hot Square 2 Square** Seven SB<br>**Tri-Hot Square 2 Square** Jailbird Cruiser<br>**Tri-Hot Square 2 Square** Seven SB Cruiser<br>**Tri-Hot Square 2 Square** Jailbird<br>**Tri-Hot Square 2 Square** Jailbird SB**<br>**Tri-Hot Square 2 Square** Rossie<br>**Tri-Hot Square 2 Square** Rossie SB | | **Ai-Dual** Double Wide DB<br>**Ai-Dual** Double Wide 1/2 Ball DB | **Ai-Dual** #1 CH** |
| MID CG | **Ai-Dual Square 2 Square** #7<br>**Ai-Dual Square 2 Square** Jailbird** | **Ai-Dual** #7 DB<br>**Ai-Dual** #7 1/2 Ball DB Cruiser<br>**Ai-Dual** Jailbird DB Cruiser<br>**Ai-Dual** Jaibird Mini DB**<br>**Ai-Dual** Jailbird Mini 1/2 Ball DB**<br>**Ai-Dual** Jailbird Mini 1/2 Ball DB Cruiser** | | **Ai-Dual** #7 S**<br>**Ai-Dual** #7 1/2 Ball S |
| BACK CG | **Ai-Dual Square 2 Square** Max 1/2 Ball**<br>**Ai-Dual Square 2 Square** Max 1/2 Ball Cruiser<br>**Ai-One Square 2 Square** Max 1/2 Ball Broomstick Cruiser<br>**TRTL MAX** S2S** | **TRTL** DB** | **TRTL** CH<br>**TRTL** S | |

** indicates available in RH & LH - All other models are RH only